



Setup Comparison LoRiser2 vs. Air Jack

<u>Air Jack</u>	<u>LoRiser2 Lift *</u>
<u>Set up</u>	<u>Set up</u>
Manually locate vehicle in work bay	Locate vehicle using spotting dishes
Bring jacks into work bay	—
Bring air line into work bay	—
Carry jack stands into work bay	—
Jack up both sides of vehicle	push 'raise' button to raise vehicle
Set up jack stands both axles	—
Lower both axles into jack stands	—
Remove jacks from work area	—
<u>Tear Down</u>	<u>Tear Down</u>
Retrieve jacks into work area	—
Jack up both sides of vehicle	—
Remove jack stands from both axles	—
Lower vehicle wheels to floor	push 'lower' button to lower vehicle
Remove jack stands from work area	—
Remove jacks from work area	—

*Users confirm time savings for setup/teardown of 45—60 minutes per job.